To start, move the switch on the battery box from DEMO to ON. Now I will respond to your voice and touch. This item includes: 1 - pet 4 - LR44 batteries I'VE GOT PERSONALITY! Ages 4+ IF I LIKE 11, PLL GLOGE, MIT ELSTADON COO SOFTLY AND TILT MY HEAD, OR CLOSE EYES AND SIGH. IF I'M FEELING GRUMPY, I'LL TURN MY HEAD AWAY AND GRUMBLE. TALK TO ME! **CUDDLE ME!** PET ME! CHILD'S HAND
I'M SMALL JUST LIKE A DE I FIT COMFORTABLY IN A **COLLECT ME!** 

Nuzzy Luvs™ ships with the batteries in DEMO mode and the batteries may be depleted. For best results, it is suggested you replace these with new batteries.

PAWS!

BIG, FLOPPY PAWS WITH EMBROIDERED PAWPRINTS

Remove all contents from package and discard any rubber bands, wire ties, or other packaging materials that are not part of the product.


Please retain these instructions as they contain important information. Read all of the instructions before use.

For more information on Nuzzy Luvs™ products please go to: www.nuzzyluvs.com

## Changing the batteries in the pet

Adult supervision is required. Open the sewn hatch on the bottom of the pet. Unscrew the battery hatch with a screwdriver. Install 4 LR 44 batteries with the positive,+ flat side up on all. Be sure the batteries are properly seated. Replace the hatch and screw snug.

Requires 4 LR44/AG13 1.5v Batteries.



Nuzzy Luvs™ has a Low Battery Alert. If your Nuzzy Luv's batteries are low, you will hear 3 "beeps". This sound will continue until the batteries are depleted. Replace the batteries after you hear the "beeps" for best performance.

## **BATTERY INFORMATION**

- Always replace used batteries with fresh alkaline batteries. Only batteries of the same or equivalent type as recommended are to be used.

  Batteries are to be inserted with the correct polarity.
- Do not mix old batteries with new, do not mix alkaline with standard carbon zinc or rechargeable nickel cadmium batteries.

  Non-rechargeable batteries are not to be recharged.

- Rechargeable batteries are to be removed from the toy before being charged. Rechargeable batteries are only to be charged under adult supervision
- Exhausted batteries are to be removed from the toy. . The supply terminals are not to be short-circuited

CAUTION • Do not dispose of batteries in fire.

- Discard old batteries in accordance with local regulation.
- Remove batteries from the device when stored

WARNING: This product contains a Button or Coin Cell Battery. A swallowed Button or Coin Cell Battery can cause internal chemical burns in as little as two hours and lead to death. Dispose chemical burns in as little as two hours and lead to death. Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention. In Australia, call the 24-hour Poisons Information Centre on 13 11 26 for fast, expert

WARNING: Dispose of used batteries immediately. Keep new and used batteries away from children. If you think batteries might have swallowedor placed inside any part of the body, seek immediate medical

Claim: This device complies with Part 15 of the FCC Rules.

Claim: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1)This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Caution: changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules.This Class B digital apparatus complies with Canadian ICES-003. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
   Increase the separation between the equipment and receiver.
   Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician for help

This Class B digital apparatus complies with Canadian ICES-003

Contains 4 LR44 button Cell batteries, included. Batteries or battery packs must be recycled or disposed of properly. When this product has reached the end of its useful life it should not be disposed of with other household waste The Waste Electrical and Electronic Equipment Regulations require it to be separately collected so that it can be treated using the best available recovery and recycling techniques. This will minimize the impact on the environment and human health from soil and water contamination by any hazardous substances, decrease the resources required to make new products and avoid using up landfill space. Please do your part by keeping this product out of the municipal waste stream! The "wheelie bin" symbol means that it should be collected as "waste electrical and electronic equipment". You can return an old product to your retailer when you buy a similar new one. For other options, please contact your local conuncil.

## www.nuzzyluvs.com

For Questions and Comments please call: 1800 225 9319



TIME TO SLEEP!

MY EYES AND START TO SNORE.
TOUCH MY HEADTO WAKE ME UP

©2020 Cepia LLC. 121 Hunter Ave. St. Louis Missouri 63124











## **WARNING:**

All rubber bands and wire ties, as well as tags, are not parts of this toy and should be discarded for your child's safety. Colors and contents may vary from those shown on the package.